



## TSB-345 ACS Conversion Flywheels

Please note that this clutch kit is designed **only** to fit an ACS conversion flywheel and will not mount to the vehicles OEM flywheel.

The ACS conversion flywheel may also be multi-drilled to suit multiple different pressure plate bolt patterns. In this instance, it is important to check which holes to use for your particular clutch kit prior to fitting the dowels and installing the clutch. To determine what bolt pattern to use for the pressure plate in this clutch kit, lay the pressure plate on the flywheel and rotate it until all dowel holes and bolt holes line up with holes on the flywheel. Check the following:

- Pressure plate bolt holes all align to a threaded hole
- · Pressure plate bolts are the correct thread for the aligned holes
- You select the correct dowel size to suit both the pressure plate and flywheel.

Note that some kits will come with a range of different dowel sizes. When you have the correct dowels, knock them into the correct holes using a hammer.















