



## TSB-177 **CAUTION!**

The bleeder tube on the concentric slave cylinder (CSC) supplied can be damaged or broken if it is handled incorrectly.

The hex tube that runs from the CSC to the bleeder nipple does not rotate. If too much rotating force is applied to the tube to tighten or loosen the bleeder nipple, the hex tube can shear off inside of the bellhousing.



It is recommended to loosen the bleed nipple initially before installing the CSC so that a second ring spanner can be used to support the hex tube and avoid excess force being applied to the CSC body.







CLUTCH AND FLYWHEEL SPECIALISTS

LEADING BRANDS









